



Hewlett Packard Enterprise

Course Datasheet

HPE BladeSystem c-Class Enclosure Management

Education Services course product number – H1RW0AAE

Course length – 1.5 Hours

Delivery mode – Web Based Training (WBT)

Register – [Click here to go to HPE Learning Portal](#)

This course explains the initial steps involved in setting up the enclosure by using the HPE Insight Display and HPE Onboard Administrator First Time Setup Wizard. The enclosure high availability is presented. Then, the Onboard Administrator configuration options are explained in the OA GUI and command line interface.

Audience

- System administrators, engineers, and consultants who integrate, manage and monitor HPE BladeSystem equipment.

Prerequisites

- Basic knowledge of HPE BladeSystem c-Class enclosures.

Course Objectives

- By the end of the course, you should be able to meet the following objectives:
 - List the initial steps involved in setting up the c7000 enclosure using the:
 - HPE Insight Display Initial Setup Wizard
 - HPE Onboard Administrator First Time Setup Wizard
 - Describe the OA enclosure high availability
 - Identify the OA configuration options
 - Describe the OA command line interface

Detailed Course Outline

- Accessing the Onboard Administrator
- Communication paths to the iLO
- HPE BladeSystem Insight Display
- Onboard Administrator First Time Setup Wizard
- Assigning management IP addresses
- Enclosure Bay IP Addressing (EBIPA)
- Demo: Using the BladeSystem Insight Display
- Enclosure High Availability
- Backing up a configuration
- Linking c-Class enclosures
- c-Class enclosure service port
- OA user accounts
- Managing iLO users
- Link Loss Failover
- Resetting an OA password
- Reseating interconnects
- Demo: Using the Onboard Administrator GUI
- Command line overview
- Using the OA CLI to reset a server blade
- CLI: hponcfg
- Demo: The OA Command Line Interface
- Learning check